1861196
Saylor Devonshire Clock

Parts Enclosed

A.	Clock Housing	1 pc
B.	Back Panel	1 pc
C.	Clock Mechanism	1 pc
D.	Battery	1 pc

* Please make sure that you have all the parts indicated above before you begin assembly of this item.

Assembly instruction

1. **Place the Battery (D)** Work from the back of the Clock Housing (A). Pull the Back Panel (B) out from the Clock Housing (A). Place "AA" Battery (D) into the Clock Mechanism (C). Adjust hand set Knob on the Clock Mechanism (C) to correct time. Replace Back Panel (B) on Clock Housing (A). See Illustration.



Illustration